

UVC Multi-Tool user's manual


1, Plug your device to Windows PC

2, Run UVC Multi-Tool, it will automatically detect the VID and PID, Click “Open Device” you will see the Descriptor:




Otherwise if no device found , please check the connection of the device.

3, Audio volume adjust function, if your device support audio volume adjusting, you will see the slider is moveable like above, otherwise they will be gray like following:




4 , Firmware updating


1) Click "FlashWrite" option:




2) Click choose file path:




3) You will see the file version if the file opened successfully :




4) Click Burn to continue :



5) Updating:




6) Click OK then **re-plug** device :




音量调节工具说明

- 1，连接需要设置的设备到微软系统的电脑。
- 2，运行 UVC Multi-Tool 工具，它会自动识别支持的硬件 VID,PID，点击“Open Device” 打开设备，可在 Descriptor 中看到设备名称。




如果无法发现设备，请在此确认设备与电脑的连接。

- 3，音量调节功能。如果您的设备支持音量调节，你会看到各个音量滑块如上图可以使用鼠标移动，否则你会看到如下图那样显示灰色。




4, 升级固件程序


(1), 点击 Firmware 固件选项:




(2)，点击选择需要升级的固件程序文件路径：




(3)，如果打开固件程序成功，你可以看到文件版本：



(4)，点击 Burn 开始烧录固件：



(5)，正在更新中：



(6)，提示更新成功后，点击确定，并再次插拔设备：

