



1.Double click below updating tool in fold.


双击文件夹中的升级工具。



2.Click below blue box. 点击下图中蓝色方框。




3.Select the .bin firmware in the fold, then click the blue box. 选择文件夹中.bin 固件程序，按 蓝色方框的“开启”。



4.Click “Update” to update firmware until appears you “Success” to finish updating.

按下 “Update” 后，显示 “Success”即完成更新。



5. Please un-plug and re-plug device from computer, then system will detect the right hardware again. 请重新插拔设备，然后系统才会正确重新识别设备。

6. We usually offer the standard firmware only on Download part of our website, please check the right product model that you bought, and download the right firmware. If you still cannot solve the problem, please go to FAQ to find out the solutions, or send us mail. 通常我们在网站下载部分仅提供标准固件程序，请确认您购买的产品信号以便下载正确的固件程序。如果仍然无法解决问题，请到网站的 FAQ 去发现解决方案，或者给我们写邮件。