尺寸：100*140MM
折页，中英文正反两面印刷

Cassette to MP3 converter

Quick Start Guide

Thanks for purchasing ezcap231 standalone cassette to MP3 converter. The following guides you how to set up. Hope this device will bring you nice digital experience.

With this ezcap231 standalone cassette to MP3 converter, you can easily convert your old tape to MP3 without a computer, you just need to plug a USB Flash disc on then press "record" button, and the device will convert all of the music on tape to your USB Flash disc in MP3 format automatically. You can also playback on it, or just put USB Flash to other place (computer, portable speaker, or transfer to your mobile phone, iPod, etc.) to play the recorded music.

Box Contents

ezcap231 Cassette to MP3 Converter
3.5mm earphone
USB power cable
Quick Start Guide

Overview



1



1. Lid switcher - Slide down to open the lid, so can put cassette in.
2. AUX port - Line out to earphone or an external speaker, or line in from audio source.
3. OTG - Plug in USB flash driver or a USB card reader with SD card, to save recorded music. Only support FAT/FAT32/exFAT formats. Please use a USB flash drive with a capacity of 32GB or less.
4. Volume control.
5. See-through window - To check if cassette is running.
6. Cassette operate buttons - See following details.
   PLAY - press to play the tape.
   DIR - Change the direction of cassette playing.
   - Auto Reverse switch, slide to engage Auto Reverse mode.
   F.F - Fast forward.
   REW - Rewind.
   STOP - press to stop playing tape.
7. DC port - 5V 1A DC. USB power adapter is not included.
8. Convert operate buttons - See following details.

⏺II	Press to start/stop record. The recorded file will be saved on USB flash drive
▶II	Press to start/stop playback
◀◀	Previous track
▶▶	1. Next track during playback. 2. Long press to switch recording modes between Manual and Auto in Standby mode. 3. On Manual record mode, press to save the recording file in USB flash drive, and start the new recording automatically.

2

+/-	Playback volume increase/decrease

LED indicator

Keep on - Standby mode, USB flash drive slotted in.
Flashes quickly (2 times per second) - Recording.
Flashes slowly (1 time per second) - Playback.
Green LED - Manual record mode.
Blue LED - Auto record mode.

Preparation before use

There are three power supply options.

Insert 2 AA batteries
You must open the lid of the cassette player to access the battery compartment. Please follow the polarity illustrations (+ or -) when inserting batteries.



Powered by computer USB port
Connect the included USB power cable with computer USB port and cassette player DC port.



3

Powered by 5V/1A USB power adapter
Connect the included USB power cable with USB power adapter/AC socket and cassette player DC port.



Cassette Operation

Play cassette tape:
1, Insert a cassette in.
2, Connect a speaker, headphone, or earbuds to "AUX" port of device.
3, Press the "PLAY" button on the top of device. You should hear the music from your cassette.
4, Adjust the volume to your comfort.

Note: To conserve battery power, the conversion mechanism will only work when there is a USB flash drive. You can still play cassette without a USB flash drive, but you cannot record without a USB flash drive.

Record / Convert cassette tape to mp3
Plug in your USB flash drive into the "OTG" port. You will see the GREEN indicator light.

Note: The device supports FAT/FAT32/exFAT formats. NTFS is not supported. Please use a USB flash drive with a capacity of 32GB or less.

4

Press the "PLAY" button on the top of device.
Press the record button (⏺) and device will begin to convert your cassette to mp3, The GREEN LED will be flashing during recording, and save the mp3 file in your USB flash drive.
Press the record button again to stop recording.

You can choose the recording mode to Manual record mode or Auto record mode.

Manual record mode:
After powering on, the device defaults to Manual record mode.
When the cassette playing and a USB flash drive is connected to the device, the device is under standby mode, the GREEN LED shows it is in Manual record mode.
In Manual record mode, you can start and stop recording at any time you like. You can also manually split the recording, to end one track and begin recording a new track.
EXAMPLE: You probably want each song to be saved in a separate mp3 file when you convert the music cassette. In this case, you can quick press the (▶▶) button between the break of the two songs. The device will save the song that just ended and start a new track for the next song.

Note: All files will be saved in the folder named "**TAPEMP3**" in the USB flash drive, and the files will be named from "**FV0001**" to "**FV9999**". A USB flash drive can only save 9999 mp3 files.



5

Auto record mode:
In Auto record mode, the device will detect pauses between songs and automatically create new tracks for each song.
To turn on Auto record mode, long press the (⏺) button for three to five seconds till the LED turns to blue
EXAMPLE: If there are six songs on one side of the cassette, the device will create seven mp3 file. File one to six are the songs, and the seventh file is an empty track for the blank space after the sixth song.
To switch back to Manual record mode, long press the (⏺) button for three to five seconds till the LED turns back to **GREEN.**
Note: If the audio is lost for a few seconds during recording, please use the USB flash drive with 40-60 Mb/S read/write speed.

Known problems in Auto record mode: This device works by detecting the level of music. You may encounter these two issues when recording in Auto record mode.
1, If there is a long pause during the song, the device may "think" it is detecting two different songs and split the recording into two separate files. In this case, we recommend using Manual record mode.
2, If the pause between two songs is too short, the device "think" it is one song, and save both songs as one file. In this case, we recommend using Manual record mode.

When you face the above issues, you can use a free software to edit your recorded mp3 files – Audacity. Please download from: **https://www.audacityteam.org/download**

Note: We don't suggest to power off or unplug the USB flash drive during recording even though the device is designed to automatically save the mp3 file for previous recording when device is powered off or USB flash is unplugged during recording.

Record / Convert via AUX port
Use the auxiliary line in port (AUX) to record music from other sources, such as the radio, mini disc, CD player, or anything with an audio line out. Use Manual record mode or Auto record mode as described above.

Note: AUX cable is not included.

Playback mp3 files:

6

The device has playback function so you can check the recorded mp3 files immediately.
Press the (▶II) playback button, the device will start to play the recorded mp3 music files, and the indicator will be flashing slowly.
Press the (▶II) playback button again to stop playback, and go back to standby mode.
During playback, use (◀◀) (▶▶) buttons to play previous or next file, And use +/- buttons to adjust playback volume.

Note: Please do not press the record button (⏺) during playback. Doing so might delete your data. You can also use the device to play other mp3 files stored in the USB flash drive, but they must be in the "TAPEMP3" folder.
Please make sure the file name of all recorded files by the device are not changed. Otherwise the files might not be played.

Specifications

Convert format: mp3
Power supply: 2 AA battery, any USB port power supply (5V DC adapter, USB form computer, etc.)
USB flash drive: Supports FAT, FAT32, exFAT formats, not NTFS. Better capacity is 32GB or less.
Working time: 2 hours with battery
Audio channel: Stereo L/R
Bit Rate: 128Kbps
Dimensions: 113(L) x 82(W) x 32(H) mm
Weight: 186g (without battery)

VER：20210708

7

盒式磁带MP3 转换器

快速入门指南

感谢您购买 ezcap231 盒式磁带 MP3 转换器，下面将指导您如何设置和操作，希望这款设备能给您带来良好的体验。
使用这款 ezcap231盒式磁带 MP3 转换器，您无需电脑即可轻松将以前的音乐磁带转换为 MP3，只需插入 U 盘然后按"录制"按钮，设备就会将磁带上的所有音乐自动以 MP3 格式复制到您的 U盘。
您也可以用转换器直接播放，或者直接将录制的MP3文件使到其他设备（电脑，便携音箱，或传输到手机，iPod等）来播放录制的音乐。

包装内容

ezcap231 盒式磁带MP3 转换器
3.5mm耳机
USB电源线
快速入门指南

预览



1



1. 磁带仓盖开关 - 向下滑动打开磁带仓盖，可以放入磁带。
2. AUX 端口 - 耳机或外部扬声器的线路输出，或音频源的线路输入
3. OTG - 插入U盘或带有SD卡的USB读卡器，以保存录制的音乐。仅支持 FAT/FAT32/exFAT 格式。
   请尽量使用32GB及以下容量U盘。
4. 音量控制。
5. 透明窗口 - 检查磁带是否正在运行。
6. 磁带操作按钮 - 见以下详细信息。
   PLAY - 按此键播放磁带。
   DIR - 改变磁带播放的方向。
   - 自动反带开关，滑动进入自动反带模式(播放磁带另外一面)。
   F.F - 快进。
   REW - 快速倒带。
   STOP - 按下停止播放磁带。
7. DC端口 – 直流5V 1A, 不包括USB接口电源适配器。
8. 转换及播放录制文件操作按钮 - 参见以下详细信息。

⏺II	按下开始/停止录音。录制的文件将保存在 U 盘上
▶II	按下开始/停止播放
◀◀	上一首曲目
▶▶	1. 播放过程中下一首曲目。 2. 待机模式下长按可在手动和自动之间切换录音模式 3. 手动录制模式下，按下会保存正在录制的音乐到U盘，并开始新的录制。
+/-	播放音量增大/减小

2

LED指示灯

保持常亮 - 待机模式, 插入 USB 闪存驱动器。
快闪 (每秒 2 次) - 正在录制。
慢闪 (每秒 1 次) - 播放。
绿色 LED - 手动模式。
蓝色 LED - 自动模式。

使用前准备

共有三种电源选项：

放入 2 节 AA 电池
您必须打开磁带播放机的仓盖才能接触到电池盒，打开电池仓盖放入电池，放入电池时请遵循极性图示（+ 或 -）。



由电脑USB端口供电
将随附的 USB 电源线与计算机 USB 端口和磁带播放器 DC 端口连接。



3

由 5V/1A USB 电源适配器供电
将随附的 USB 电源线与 USB 电源适配器和交流插座和盒式磁带播放器 DC 端口连接。不包括USB电源适配器，可以使用5V的USB接口手机充电器配合配备的USB电源线即可。



磁带MP3转换器操作

播放盒式磁带：
1. 放入磁带。
2. 将扬声器, 耳机或耳塞连接到设备的 "AUX" 端口。
3. 按下设备顶部的 "播放" 按钮。您应该会听到磁带中的音乐。
4. 根据您的舒适度调节音量大小。

注意：为了节省电池电量, 转换机制仅在有 U盘时才起作用。您仍然可以在没有 U盘的情况下播放磁带，但如果没有 U盘，您将无法录音。

录制/转换盒式磁带为 mp3文件
将您的 U盘插入 "OTG" 端口。您将看到绿色指示灯亮起。
注意：设备支持 FAT/FAT32/exFAT 格式, 不支持 NTFS, 请使用容量不超过 32GB 的 U 盘。

4

按设备顶部的"播放"按钮。
按下录制按钮 (⏺)，设备将开始将您的磁带转换为 mp3。录音过程中绿色 LED 会快闪, 并将 mp3 文件保存在您的 U盘中。
再次按下录音按钮停止录音。
您可以选择录制模式为手动录制模式或自动录制模式。

手动录制模式：
上电后, 设备默认为手动录制模式。
当播放磁带和 U 盘连接到设备时, 设备处于待机模式, 绿色 LED 显示其处于手动录制模式。
在手动录制模式下, 您可以随时开始和停止录制, 您还可以手动拆分录音, 以结束一首曲目并开始录制新曲目。
示例：您可能希望在转换盒式磁带时将每首歌曲保存在一个单独的 mp3 文件中。在这种情况下, 您可以在两首歌曲的中断之间快速按下 (▶▶) 按钮。设备将保存刚刚结束的歌曲并开始下一首歌曲的新曲目。

注意：所有文件都将保存在U盘中名为"**TAPEMP3**"的文件夹中, 文件名将从"**FV0001**"到"**FV9999**"。U 盘最多只能保存 **9999** 个 mp3 文件。

5

自动录制模式：
在自动录制模式下, 设备将检测歌曲之间的间隙并为每首歌曲自动创建新曲目。
要打开自动录制模式, 请长按 (⏺) 按钮三到五秒钟, 直到 LED 变为蓝色。
示例：如果磁带的一侧有六首歌曲, 设备将创建七个 mp3 文件。一到六为歌曲, 第七个为第六首歌曲后的空白文件。
要切换回手动录制模式, 请长按 (⏺) 按钮三到五秒钟, 直到 LED 变回绿色。
注意：如果录音过程中音频会丢失几秒钟, 请使用40-60 Mb/S读写速度的U盘。

自动录制模式中的已知问题：该设备通过检测音乐音量来实现自动分割。在自动录制模式下录制时, 您可能会遇到这两个问题。
1. 如果歌曲播放过程中出现长时间停顿, 设备可能会"认为"是两首不同的歌曲, 并将录音拆分为两个单独的文件。在这种情况下, 我们建议使用手动录制模式。
2. 如果两首歌曲之间的停顿太短, 设备会"认为"是一首歌曲, 并将两首歌曲保存为一个文件。在这种情况下, 我们建议使用手动录制模式。

当您遇到上述问题时, 您可以使用免费软件来编辑您录制的 mp3 文件 - Audacity。请至以下链接下载：**https://www.audacityteam.org/download**

注意：即使该设备设计了在设备断电或在录音过程中拔下 U 盘时会自动保存录制的 mp3 文件, 我们仍然不建议在录音过程中关闭电源或拔下 U 盘。

通过 AUX 端口录制/转换
使用外部线路输入端口 (AUX) 录制来自其他播放器的音乐, 例如收音机, 迷你光盘, CD 播放器或任何带有音频线路输出的设备。可以使用手动录制模式或自动录制模式录制音频文件。
请使用AUX线 (视不同的播放设备而定, 转换器这边需要连接3.5mm立体声音频接头) 来连接转换器的AUX接口和其他音乐播放器的音频输出接口。
注意：包装内并不包括 AUX 电缆, 请自行购买。

播放mp3文件：
该设备具有播放功能, 您可以立即播放录制的 mp3 文件。
按播放键 (▶II), 设备开始播放录制的mp3音乐文件, 指示灯慢闪。
再次按下播放按钮 (▶II) 停止播放, 并返回待机模式。
在播放过程中, 使用按钮 (◀◀) (▶▶) 播放上一个或下一个文件, 并使用 +/- 按钮调整播放音量。
注意：播放过程中请勿按录音键 (⏺), 这样做可能会删除您的数据。您也可以使用该设备播放 U 盘中存储的其他 mp3 文件, 但mp3文件必须存放于"TAPEMP3"文件夹中。请确保设备录制的所有文件的文件名未更改。否则文件可能无法播放。

6

规格

转换格式: mp3
电源: 2节AA电池, 任意USB口供电 (5V DC适配器, 带USB接口的电脑等)
U 盘: 支持 FAT, FAT32, exFAT 格式, 不支持 NTFS, 最大支持的容量是 32GB。
工作时间: 电池2小时
音频通道: 立体声左/右声道
比特率: 128Kbps
尺寸: 113(长) x 82(宽) x 32 (高) 毫米
重量: 186g (不含电池)

VER：20210708

7