

SHARPSTAR color carbon

Name of Each Component:

- ① Declination body
- ② R.A. body
- ③ Cable for connecting Dec. and R.A.
- ④ Tripod head
- ⑤ Azimuth adjustment post
- ⑥ Azimuth adjustment knobs
- ⑦ Thumb screws for fixing EQ mount on tripod
- ⑧ Counterweight bar
- ⑨ Counterweight
- ⑩ Hand controller connecting cable
- ⑪ Hand Controller

Assembly steps:

1. Unscrew the MARK III body fixing screws ⑦;
2. Gently put the main body of Mark III onto the tripod head;
Note: The central metal protrusion should fit into the hollow on the bottom of the mount and the azimuth adjustment post ⑤ should fit into the space between two azimuth adjustment knobs ⑥;
3. Thread two thumb screws ⑦ to fix the main body of the mount firmly on the tripod head;
4. Connect the cable ③ between the Declination and R.A. body;
5. Thread the counterweight bar ⑧ into the bottom of the Declination body ②;
6. Screw the counterweight ⑨ onto the counterweight bar ⑧;
7. Connecting the handle controller data cable ⑩ to the rear side of the MARK III body.



Mark III Instruction Manual



<http://www.sharpstar-optics.com/index.php/harmoniceqmount.html>