



## UVC Multi-Tool user's manual

- 1, Plug your device to Windows PC
- 2, Run UVC Multi-Tool, it will automatically detect the supported devices, you should see this if the device is connected well to computer:




Otherwise if no device found , please check the connection of the device.

- 3, Audio volume adjust function, if your device support audio volume adjusting, you will see the slider is moveable like above, otherwise they will be gray like following:




#### 4 , Firmware updating


1) Click Firmware option:




2) Click choose file path:




3) You will see the file version if the file opened successfully :




4) Click Burn to continue:




5) Updating:




6) Click OK then **re-plug** device:



7) Sometimes you need to select **Entire Flash** and to successfully update if you update firmware but nothing changed.




5, Some version such as ezc326Q can be set to different status indicator light effects.




## 音量调节工具说明

- 1, 连接需要设置的设备到微软系统的电脑。
- 2, 运行 UVC Multi-Tool 工具, 它会自动识别支持的硬件设备, 如下图。




如果无法发现设备, 请在此确认设备与电脑的连接。

- 3, 音量调节功能。如果您的设备支持音量调节, 你会看到各个音量滑块如上图可以使用鼠标移动, 否则你会看到如下图那样显示灰色。




#### 4, 升级固件程序


(1), 点击 Firmware 固件选项:



(2)，点击选择需要升级的固件程序文件路径：




(3)，如果打开固件程序成功，你可以看到文件版本：







(4)，点击 Burn 开始烧录固件：




(5)，正在更新中：



(6)，提示更新成功后，点击确定，并再次插拔设备：



(7), 一些时候你升级成功后发现什么也没有改变, 这时或许你需要选择 **Entire Flash** 并再次升级。请轻易不要使用该方式, 以免损坏 FLASH。



5, 部分型号 (比如 **ezcap326Q**) 可以使用小工具来设置不同的状态灯效。

