

We would you like to thank you for choosing an our product. You have made an excellent decision.
The following contents guide you how to use the product. Hope this device will bring you nice digital experience

Overview

The **USB Video Capture**, it can capture High-quality video and audio file directly by USB 2.0 interface without sound card. And edit them, burn DVD disc, convert them, and send them to your iPod, PSP, or 3GP Mobile Phone. And upload the video to YouTube too.


The **USB Video Capture**, it can capture High-quality audio file directly by USB 2.0 interface alone. And edit them, burn Audio CD, or MP3 CD.

The **USB Video Capture** includes a professional video editing and converting software – “ArcSoft ShowBiz 3.5”. It can provide best editing and converting function for you. ShowBiz 3.5 is a video-editing and converting software that makes editing your videos as fun as shooting them. ShowBiz 3.5 helps novice users finish stylish movies in only few steps. Share finished projects on DVD, tape, the Web, and mobile devices.
The converting function, it help you to convert the vedio file you recorded as MPEG4, AVI, and other file format, then you can send converted videos to your iPod, PSP, 3GP Mobile Phone, or other vedio device.


Specification

Item Name	USB 2.0 Video Capture
Interface	USB 2.0 standard
TV System	PAL, NTSC
Recording Format	MPEG2 for Video
Converting Format	Video: Apple TV, iPhone, iPod classic, iPod nano, iPod touch, WMA. ASF, MPEG1, MPEG2, WMV
Input	Composite Video(RCA), S-Video(miniDIN 4pin), Audio L/R(RCA)
Resolution	NTSC 160×120 ~ 720×480, PAL 160×120 ~ 720×576
Rate	NTSC 30fps, PAL 25fps
Power Supply	USB Bus
Consumed Power	≤ 1.5W
Editing Software	Video: ArcSoft ShowBiz 3.5
Dimension / Weight	90(L)×44(W)×28(H)mm / 72g
Cable Length	80cm(USB), 7cm(Video/Audio)
System Requirements	One available USB 2.0 port
	Pentium4 CPU or above
	512MB RAM or above
	Graphics card supports DirectX 9.0C
	1GB free HDD space
	CD-ROM for installation
	DVD-R/RW for burning DVD
	Windows XP, Vista,Seven, Eight
	Video Capture device, Software CD(includes driver, application and manual)

Connection Guide



If you use a scart interface, please connect equipment following below picture and set the switch to be OUTPUT.



Notice:

1, You maybe have to buy Video and Audio cable, and S-Video cable to connect the USB Video Capture with your analog video device. You need to buy the Scart Video/Audio adapter if the output of your video source device is Scart type.

2, The following devices can be used as analog video sources:


Video recorder, DVD player, Video camera, Set-top box, Game player and any device that provides an analog video signal.

Hardware Installation:


Note: If you have any antivirus software enabled, please disable it during the installation of the software. Before you first connect the **USB Video Capture** to your computer, please insert the “CD-ROM” into your CD drive. Then you should find a picture of software running.



Please select the option “Install Driver”. And system will appears you as below picture. Please click “Next” key to continue the installation.



You will get another picture, please click “Finish” key.




System will appear you to restart your computer, please select “Yes, I want to restart my computer now.” and click “Finish” key to restart your computer.

Now you need to plug the **USB Video Capture** into USB 2.0 port.

If prompted select “No, not this time” and select “Next”. Select the option “Install the software automatically” and click “Next”.


When “Completing the Found New Hardware Wizard” window appears click the “Finish” button to complete the driver installation.

You will now need to check that the drivers are installed correctly. Connect the device to your computer, Right Click on My Computer and Left Click on properties. Click on Hardware tab and then Device Manager. In the Device Manager click on the “Sound, video and game controllers” correctly you should see the “ezcap Video Grabber”, If it has a Yellow mark next to it then this means that the driver is not installed correctly. You will need to remove the driver and disconnect the device from the computer and reconnect it to install the driver again.




ShowBiz 3.5 Installation & Guide:


Please back to software running picture, and option "Install ShowBiz 3.5" and select your language for the installation. And click "Next" or/and "Install".




You need enter user name and serial number (you can find out the serial number on CD-ROM bag).



System will install the software, and you can choose destination location and folder. Then click “Next” to continue installation.



Click “finish” to complete setup, restart your computer if needed.




Capture video

Now, you need to set software for capturing and editing video and audio.


Double click “ShowBiz 3.5” icon on your desktop, and click Capture button to enter into the capture panel.

On the capture panel, please set “Source” to be “ezcap Video Grabber”, and you must click “Audio Device” to select “USB Pin Source” option.

Please set “Video input” to be “Composite” or “S-Video” according to the connection of the device.



You can click “Device Settings” to choose “NTSC_M”, “PAL_B” and others for your TV system.



After all that, you can browse the video on the window of the player software.

Record video

On the capture panel, please click "Record" button to record your video. When you want to stop the recording, please click "Record" button again.

You can save your video files with MPEG2 format, and you can change the saved folder for your recorded videos

Edit video

Please click "Edit" key or close the player window to edit your video files. The first, please select the video file you want to edit, then you can choose the various effects to edit them according to your needs.

Also you can edit your pictures or audio files with ShowBiz 3.5, the first, select Picture or Audio option, then click "Open" to choose the file and edit them.



Save, convert or upload videos

You can click "Produce" button to enter into the following panel, then you can select function to handle your recorded video, audio file, or pictures according to your needs.

As creating video file:

The first, please select the file you want to create, and click "Create File" button to enter into the Create File panel.

On the panel, if you set Type to be PMP, you can create file with Apple TV, iPhone, iPod classic, iPod nano, or iPod touch format.

If you set Type to be Disc, you can create file with DVD, SVCD, or VCD format.


If you set Type to be File, you can create file with WMA, ASF, MPEG1, MPEG2, or WMV format.

Also, you can create your video file with DVD model, or upload them to a YouTube



Get help file

For more detailed instructions for using ShowBiz3.5, please click "Option" button on panel to select Help to get them.



How to uninstall ShowBiz 3.5

If you want to uninstall the ShowBiz 3.5, please insert the installation CD into the CD-ROM, Then you should find a picture of software running. Please select "Install ShowBiz 3.5", and select "Remove" to uninstall ShowBiz 3.5.

