

1, We do not recommend upgrading the firmware without encountering actual failures, as improper operation may crash the device.

如果您的设备没有实际的故障, 我们不建议您升级固件程序, 因为操作不当可能会让机器崩溃。

2, Plug device to USB port (or Type-C) of computer with Windows system.

将设备与电脑的 USB 或 Type-C 接口连接, 电脑必须是 Windows 系统.


3, Double click updating tool – “ezcap32x_HidTool.exe” , and click **1 (Open Device)** and **2(Get ID)** of below picture, then click **3(Burn File)** to select the firmware document like “320_1_3_8_4_1230_default1080.hex” , then tick **4 (Entire Flash)**, and click **5 (Burn)** to start updating firmware.

Note: The default PID of tool is 3200, please check the four-digit PID number of the device before you updating, then fill in the blank instead of 3200. Right click the device name under Cameras / Device Manager – Property – Event – Information - USB\VID_32ED&PID_XXXX\ . Maybe you cannot open device if you don’ t fill the right PID number.

双击打开升级工具 – “ezcap32x_HidTool.exe” , 依次点击下图中 **1 (Open Device)** 和 **2(Get ID)**, 再 点 击 **3(Burn File)** 并 选 择 需 要 升 级 的 固 件 程 序 , 比 如 “320_1_3_8_4_1230_default1080.hex” , 再勾选 **4 (Entire Flash)**, 最后点击 **5(Burn)** 开始升级.

注: 升级工具默认的设备 PID 为 3200, 请在升级前先确认您的设备的 PID, 然后将正确的 PID 四位数填入进去以代替 3200。右击设备管理器-相机下的设备名称 – 属性 – 事件 – 信息 - USB\VID_32ED&PID_XXXX\。如果没有输入正确的 PID 号可能导致无法打开设备

以升级固件。



4, It means updating successfully until appears you the below window. Please replug-in device.

直到弹出如下窗口, 则表示升级成功. 请重新插拔设备.

