





# Ezcap159 USB FW Update Procedure 更新固件程序

1. Find you Windows Device manager and make sure you EM28284 USB Driver installed well. 请在设备管理器确认你的设备是否已经安装好.



2. Find USB FW Update Tool and Open it, \\_EM28285-UAC-FW\_D110819\\_V\FwDnApp\_D071719.exe  
Press Download Button to Start FW Update. 双击打开 FwDnApp\_D071719.exe, 点击右下角 Download 按钮开始更新固件.



3. FW Update will finish in 3 second. And show Green PASS . After FW updated, You have to Unplug USB once to get new FW Running . 大约 3 秒后会完成固件更新, 并出现绿色的 PASS 字样. 固件更新后, 需要重新插拔设备来让新的固件运行.